

LED Indicators

Freedom Collar Lights

Event	Color
Bootup	White
Low Battery	Red
Geofence Violation	Red blinking (quick flash then slow flash)
Geofence Violation Recovery	Green for 2 seconds
Manual Correction	Red slow flash until correction is completed
Safety Light	White
Ready to Connect, Pairing Mode	Blue blinking continuous
Connected to Wi-Fi for the First Time	Green blink 3x
SW Update In Progress	Purple blinking continuous
Activation Success	Green blink 3x
Activation Failure	Red blink 3x
Collar Has No Network Connection	White blink every 30 seconds
Collar Error - Contact Support	Red blinking continuous

Freedom Collar Charger Lights

Event	Color
Charger Plugged Into Power Source With No Battery Installed	No Light
Battery Charging	Red
Battery Fully Charged	Green